

SKIP*HOP®

9H498210-05

0-6
m

MOBY® recline & rinse bather



OWNER'S MANUAL

© Skip Hop, Inc.

All rights reserved. SKIP HOP, MOBY and MUST-HAVES MADE BETTER are trademarks owned by Skip Hop, Inc.

100 W 33 ST, STE 1125, NY, NY 10001
In the US: 888.782.9548
www.skiphop.com

Meets or exceeds applicable safety standards.



For US/Canada customer only:

⚠️ WARNING:

DROWNING HAZARD: Babies have **drowned** while using infant bathers and infant bath tubs.

To prevent drowning:

- **STAY** in arm's reach of your baby.
- **Never** rely on a toddler or preschooler to help your baby or alert you to trouble. Babies have drowned even with other children in or near bath tub.
- Babies can drown in as little as **1 inch** of water. Use as **little water as possible** to bathe your baby.
- Use **ONLY** in **empty** adult tub or sink.
- Keep drain **open** in adult tub or sink.

FALL HAZARD: Babies have suffered **head injuries** falling from infant bathers and infant bath tubs.

To prevent falls:

- Place infant bather/infant bath tub **ONLY** in adult tub, in or next to sink.
- **NEVER** lift or carry baby in the product.
- **STOP** using product when baby starts trying to sit up or has reached 20 lbs. (9 kg) whichever comes first.
- **STAY** in arm's reach of your baby.
- This product does not offer any additional safety related to water hazard.
- This is **NOT** a safety device.
- Always use this product inside a larger empty bathtub, or on a flat & stable surface.
- Never leave child unattended.
- Adult supervision required. Discontinue the use of the product if it becomes damaged, broken, or disassembled. Test the temperature of the water prior to placing the infant into the product. The typical water temperature for bathing a baby should be between 90 and 100°F (32.2 and 37.8°C).


Outside the US/Canada:

WARNING-Not a safety device.


WARNING-DROWNING HAZARD-Children have drowned while bathing and using bathing aid products. Children can drown in as little as 2 cm of water in a very short time. Always remain in contact with your child during bathing. Never leave your baby unattended in the bath, even for a few moments. If you need to leave the room, take the baby with you. **DO NOT** allow other children (even older) to substitute for an adult. Stop using the product when your child can sit unaided. Babies and young children are at risk of drowning when being bathed. Never use this product on an elevated surface not intended for this product. To avoid scalding by hot water, position the product in such a way to prevent the child from reaching the source of water. Always check the water temperature before bathing the child. The symbol **MAX**  on the product is used to indicate the maximum level of water. Do not fill water exceeding this symbol while using the product. Check the temperature of the water surrounding the product prior to placing the child into the product. The typical water temperature for bathing a child is between 35 °C and 38 °C. Always check the stability of the product before use. Do not use the product if any components are broken or missing. Do not use replacement parts other than those approved by the manufacturer. Prevent drowning. Always keep your child within arm's reach.

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

3 WAYS TO BATHE:



In the bathtub




Beside the sink




In the sink

INSTRUCTIONS:


1. Adjust recline position: press buttons on both sides of legs while rotating legs into one of two positions. You will hear a "click" when the legs are locked in place.




High Recline



Low Recline



Storage Position



IMPORTANT: Make sure both legs are locked in place before placing baby into Bather. While bathing your child, swivel the hook under the tub so it is not accessible to the child.

2. Position bather next to sink or inside **EMPTY** sink or bath tub. Place baby in Bather.



IMPORTANT: Do not place bather into a sink or tub that contains any water.

3. Fill product with water. Do not fill water past **MAX**  line marked on both sides of product.



Or - open drain plug to allow water to flow over baby and into empty sink or tub.





IMPORTANT: Make sure sink or tub drain is open. Do not allow baby to lay in Bather with a full sink or tub.

4. After bath time is over, pull drain open and allow all the water to drain out.




MAINTENANCE:

After each use:
Fold flat and hang to dry and store.



Before each use:
Check to ensure that the legs are snapped securely into place. Check to ensure that no parts are missing or damaged.



CLEANING AND CARE:

Rinse after each use. Clean with a damp cloth and mild soap.